

# ZyXEL ZyAIR main antenna position

Model name	Main antenna position (positive side)
ZyAIR B-420	Left side
ZyAIR B-1000 V.2	Left side
ZyAIR B-2000V.2	Left side
ZyAIR B-3000	Left side
ZyAIR B-4000	Left side
ZyAIR B-5000	Right side
ZyAIR G-1000	Left side
ZyAIR G-2000	Right side
ZyAIR G-3000	Right side
ZyAIR G-4100	Right side
ZyAIR G-5100	Right side
Later ZyAIR products	Right side

Positive side (LED is in front of you)

Transmit

B-4000 main antenna can be selected/configured from UI.

